



AUDAC

Connections RJ45 DW3018/4018

Pin 1	Do not connect
Pin 2	Do not connect
Pin 3	+24V DC
Pin 4	RS485 A
Pin 5	RS485 B
Pin 6	GND
Pin 7	Do not connect
Pin 8	Do not connect

Enkel aan te sluiten door een vakman
Connections only to be made by professionals
Seulement à brancher par un professionnel
Nur anzuschließen von einem Fachmann

ATTENTION

Only connect the DW3018/4018 wall
panels to your matrix system when
it's powered off

Only connect Pins 3 to 6 of the RJ45
connector