

Rega Planet & Jupiter CD Remote Control Data.

Function	Code	Hex	Comments
Shuffle	00000000	00	
Repeat	00000001	01	
Time	00000010	02	
Program	00000011	03	
Check	00000111	07	
Clear	00001000	08	
1	00001001	09	
FR	00001010	0A	
Pause	00001011	0B	
4	00001101	0D	
Previous	00001110	0E	
Stop	00001111	0F	
7	00010001	11	
0	00010010	12	
Play	00010011	13	
Play/Pause	00010100	14	
8	00010101	15	
>10	00010110	16	Not used on the original Planet - only used on the Planet 2000.
9	00010111	17	
Display	00011000	18	
5	00011001	19	
Next	00011010	1A	
6	00011011	1B	
2	00011101	1D	
FF	00011110	1E	
3	00011111	1F	

Rega Planet & Jupiter CD Remote Control, Customer Code and System Type.

Customer Code (HEX)	System	Comments
916E	NEC	

Rega Amplifier Remote Control Data

Function	Command Address	Command Code	Comments
Phono	1	000001	
CD	2	000010	
Tuner	3	000011	
Line1 (Aux)	4	000100	Aux1 on early units
Line2 (Aux)	5	000101	Aux2 on early units
Tape 1	6	000110	
Tape 2	7	000111	
Mute	13	001101	
Volume Up	16	010000	
Volume Down	17	010010	
Mono	36	100100	Only used on the HAL Pre-Amplifier.

Rega Amplifier Remote Control System Type

System	Comments	
Phillips RC5		

Rega Radio Remote Control Data.

Function	Code	Hex	Comments
Preset UP	11010001	D1	
Preset Down	11010010	D2	
FM	10000001	81	
AM	10000010	82	

Rega Radio Remote Control, Customer Code and System Type.

Customer Code (HEX)	System	Comments
877C	NEC	